ABSOLARE Bybee Purifier User Manual



1. General Description

The Absolare Bybee Purifier is a passive mains distribution device which employs non-current limiting EMI/RFI filtering devices designed by Jack Bybee. There are six European Schuko or three duplex US outlets.

2. Safety Issues and Warnings

- Total current drawn from all outlets should not exceed 12 amperes.
- There are no user serviceable parts inside the chassis. Do not open covers.

3. Operating the Unit

AC power input is via a standard IEC input socket on the back cover.

There is no power switch on the unit, mains voltage will be available at output outlets as soon as the input power is connected.

If the total current drawn from the outlets exceeds 12 amperes, the circuit breaker on back of the unit is tripped. In that case you should unplug the faulty unit and push the button on the circuit breaker. The unit returns to normal operation.

The two outlets closest to the IEC input socket are directly connected to the mains input, bypassing the Bybee filter inside.

Feet can affect the sound quality significantly. You can use either three or four feet. Adjusting their position will also affect the sound to varying degrees, depending on the type of rack, location or interaction with other equipment.

4. Technical Specifications

Type: Passive Electrical Mains Distribution Device.

Application: The device is designed to supply an entire audio system with AC power.

AC Input: The device can be used with any AC electrical mains supply from 110 to 240 Volt. There is a 12A circuit breaker.

AC Outputs: Available in two versions both with six outlets – six European Schuko outlets or three sets of duplex US outlets.

Components: Oyaide Silver/Palladium coated IEC receptacle. Oyaide Silver/Palladium coated AC outlets. Echole Obsession Signature power cable internal wiring. Jack Bybee designed non-current limiting EMI/RFI filtering devices. Mundorf custom SilverGold 800AC capacitors. Absolare's proprietary resonance control composite is applied throughout.

ABSOLARE USA LLC

40 Pemberton Road, Nashua New Hampshire, 03063

Phone: +212-229-1842

E-mail: info@absolare.com

ABSOLARE SERVICE EUROPE

Mozartstraat 157, 1962AL Heemskerk, Netherlands

Phone: +31 61 399 3049

E-mail: info@absolare.nl